

Texsalón Refuerzo

GENERAL

Texsalon Refuerzo is a nominal 0.045" (1.14 mm) thick reinforced TPO membrane strip with a nominal 0.035" (0.89 mm) thick, fully-cured synthetic rubber pressure sensitive adhesive laminated along one edge. The pressure sensitive adhesive is non-staining and will not affect the color of the membrane over time. The reinforced TPO membrane is 6" (150 mm) wide while the adhesive strip is 3" (75 mm) wide.

TYPICAL PROPERTIES AND CHARACTERISTICS*

Base	Membrane-TPO (Polyester Reinforced) Adhesive-Synthetic Rubber
Thickness	Membrane 0.045" (1.14 mm) Adhesive 0.035" (0.89 mm)
Size	6" x 100' (150 mm x 30.5 m)
Packaging	200 lf/ctn (60 m) - 2 rolls
Weight/Carton	40 lbs. (18.1 kg)
Shelf Life	1 year

CAUTIONS AND WARNINGS

- Texsalon Refuerzo may only be installed on horizontal surfaces.
- Texsalon Refuerzo must be stored in a dry area.
- Review the applicable Material Safety Data Sheet for complete safety information prior to use.
- Due to solvent flash-off, condensation may form on freshly applied HP-250 Primer when the ambient temperature is near the dew point. If condensation develops, the application of primer and installation must be discontinued as proper adhesion will not be achieved. Allow the primer surface to dry and apply a thin freshener coat of HP-250 Primer to the previously coated surface when conditions allow.
- Job site storage temperatures in excess of 90 °F (32 °C) may affect product shelf life. Prolonged job site exposure to temperatures below 40 °F (4 °C) will cause the tape adhesive to lose tack and in extreme cases not bond to the membrane. If this situation is encountered, remove Texsalon Refuerzo to a warm area and allow it to return to a minimum of 60 °F (15 °C).
- Keep out of the reach of children.

Texsalón Refuerzo

APPLICATION

- Unroll and position Texsalon Refuerzo horizontally at the base of a parapet wall or curb. Locate the tab with fastener markings toward the wall and the pre-applied tape toward the field of the roof and facing upwards.
- Remove any dirt or dust resulting from plate installation. Any residual dust/dirt will be detrimental to the bond strength of the tape adhesive.
- Position deck membrane and thoroughly clean the underside of the deck membrane using Weathered Membrane Cleaner if necessary. (The entire surface where the tape is to contact must be clean. The adhesive on the Texsalon Refuerzo will not adhere to dusted / dirty surfaces).
- Roller apply HP-250 Primer to the underside of the deck membrane in the area that will come in contact with the 3" wide tape. The properly primed area will be uniform in color without streaks and free from globs or puddles.
- Remove the release liner from the adhesive tape on the TPO Texsalon Refuerzo pulling it parallel to the roof deck.
- Roll the deck membrane onto the exposed adhesive tape and apply hand pressure to the splice area.
- Pull the membrane back to expose the unadhered portion of the Texsalon Refuerzo. Apply Texsalon Refuerzo, exposed Texsalon Refuerzo and parapet wall.
- Once the adhesive has dried, roll membrane to the angle change and crease. Roll the membrane up the wall and broom for 100% adhesion.
- Roll the entire 6" (150 mm) width of the Texsalon Refuerzo splice area with a 2" (50 mm) wide roller using positive pressure.
- To achieve proper adhesion of the Texsalon Refuerzo when job site temperatures fall below 40 °F (5 °C), heat the cleaned / primed area of the membrane with a hot air gun as the flashing is applied and pressed into place.

* General properties. Typical properties and characteristics are based on samples tested and are not guaranteed for all samples of this product. This data and information is intended as a guide and does not reflect the specification range for any particular property of this product.